



DUCATO 2.0 16V STEERING COLUMN TRIM - R+R 7040A26

[back to MOUNT WITH STEERING CONTROL SHAFTS - RR - INCLUDES RR STEERING WHEEL FOR VERSIONS WITH AIR BAG](#)



Removing ([Refitting](#))

1. Undo the bolts (1a) and remove the steering column front cover (1b).



1. Undo the bolts (1a) and remove the steering column rear cover (1b).

Refitting ([Removing](#))

- Position the steering column rear cover and tighten the fixing bolts.
- Position the steering column front cover and tighten the fixing bolts.