

NUOVO DUCATO X250 2.2 JTD CENTRAL LOCKING / NOT WORKING WITH REMOTE CONTROL P11

When the door closing/opening is controlled using the remote control, the central locking does not work.



The Body Computer Node receives the signal from the remote control via the RF aerial. Having received the command, it sends the opening/closing signal to the door actuators and to the luggage compartment actuator.

		TEST RESULTS		
0	PRELIMINARY CHECK	ALL OK	PROBLEMS ENCOUNTERED	ACTION
	Activate the closing/opening of the doors using the second remote control that comes with the vehicle.	Move on to Step 1	1. Problem persists. 2. The system works using the second remote control	1. Move on to Step 1 2. Replace the defective remote control and program the new remote control in the Body Computer
1	REMOTE CONTROL BATTERY CHECK	ALL OK	PROBLEMS ENCOUNTERED	ACTION
	Check that the remote control battery is not run down.	Move on to Step 2	Battery run down.	Replace the remote control battery.
2	CHECK USING DIAGNOSTIC EQUIPMENT	ALL OK	PROBLEMS ENCOUNTERED	ACTION
	Connect the Examiner diagnostic equipment to the Body Computer and check that there are no errors.	Move on to Step 3	Error detected: RF receiver broken	Move on to step 4
3	CHECK USING DIAGNOSTIC EQUIPMENT	ALL OK	PROBLEMS ENCOUNTERED	ACTION
	Keeping the diagnostic equipment connected to the Body Computer node, check the following in the parameters mode: - that the remote control is correctly programmed; - the operation of the individual remote control buttons.	Move on to Step 4	1. Remote control not properly programmed. 2. Remote control buttons malfunction.	1. Programme the remote control. 2. Move on to Step 4
4	ELECTRICAL CIRCUIT CHECK	ALL OK	PROBLEMS ENCOUNTERED	ACTION
	Check that the RF receiver aerial is not interrupted or incorrectly connected to the Body Computer.	Move on to step 5	1. Aerial lead broken. 2. Aerial lead connector not correctly connected to the Body Computer.	1. Restore the continuity/insulation of the aerial lead See E3040 CENTRAL LOCKING Correctly connect the aerial lead connector to the Body Computer.
5	CHECK ON COMPUTER CORRECT OPERATION	ALL OK	PROBLEMS ENCOUNTERED	ACTION
	Check that the body computer is working properly	End of diagnosis.	The fault persists.	Replace Body Computer Op. 5505A35 MAIN BODY COMPUTER/JUNCTION UNIT - R.R.