


Ducato X230 Ignition Switch



When reading this diagram, the connections are to the open rectangles, or squares at the sides, There is a connection across the diagram where a black square is shown in the selected position. For example in the PARK position, the supply at A1, is connected to the side & rearlights at B4,. There are no other connections with the key in this position.